

POWERFLEX®

PART NUMBER
PFR5-606

DESCRIPTION
REAR TRAILING ARM BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 8 x bushes (4 A parts & 4 B parts)
- 4 x stainless steel sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Before removing the original bushes note that the original bushes are offset in the arm.
2. The new bushes comprise of an A & B polyurethane part, the A part has a thicker top section and the B part a thinner.
3. Remove the original bush from the arm, clean any dirt, rust and sharp edges from the hole.
4. Fit the A bush (thicker) from the inside face out-wards and the B bush (thinner) from the outside face in-wards replicating the offset of the original bush.
5. Apply some of the supplied grease to the bore and end faces of the bushes.
6. Fit the sleeve into the bush.
7. Refit to the car following manufactures guide and torque settings.

