



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [10 in.] clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template Radi-CAL Competition Package Chevrolet Gen. 5 Camaro, Rear CP9450 Caliper, 365 mm Disc	essex parts services, inc. www.essexparts.com	
	Essex package no. 13.01.10133	DWG. NO. 2049 REV