

POWERFLEX®

PART NUMBER
PFF85-602

DESCRIPTION
FRONT ARM REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane A Bushes

2 x Polyurethane B Bushes

1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the front wishbone from the vehicle. This will require the arm to be removed from the rubber bush that will remain in the bush console.
2. Leaving the console bolted to the subframe, completely remove the original bush by cutting it out or using a puller.
3. Clean away any dirt and corrosion from the console and wishbone, using a rounded file to remove any sharp edges to prevent damaging the new bush.
4. Press the larger B Bush into the console using either a puller in reverse or clamps.

Tip: To make the fitting of the larger B Bush easier, apply some washing up liquid onto the chamfered lip, and press with the bush at a slight angle.

5. Push the smaller A Bush onto the hexagonal pin of the wishbone.
6. Apply some of the supplied grease to the bore of the larger B Bush and the outside of the smaller A Bush.
7. Refit the arm onto the car, and tension all hardware to the manufacturer's recommended torque settings.

