



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

**Wheel Clearance Template**

World Radi-CAL II Road Package  
 BMW E9X and F8X, REAR  
 CP9541 caliper, 380 mm disc

Essex package no. 20.01.10008 (E9X)  
 20.01.10010 (F8X)

**essex parts  
 services, inc.**  
 www.essexparts.com

DWG. NO. **1898**

REV

5

4

3

2

1