

# POWERFLEX®

## PART NUMBER

**PFR5-4026**

## DESCRIPTION

REAR DIFF REAR MOUNTING BUSH

## INSTALLATION GUIDE

### **Product description:**

This part replaces OE number: 33177852495.

### **Contents (parts per pack):**

- 1 x Polyurethane A Bush
- 1 x Polyurethane B Bush
- 1 x Aluminium Sleeve
- 1 x PTFE / Silicone Bush Assembly Grease

*Please read the complete fitting instructions and check package components before fitment.  
These fitting instructions are to be used as a guide and in conjunction with workshop manual.  
It is recommended that:  
-all work to be carried out by a licensed technician;  
-all safety precautions adhered to;  
-wheel alignment to be checked and adjusted as required after any suspension work.  
All fasteners must be tensioned to manufacturer's torque settings.*

### **Fitting Instructions:**

1. Remove the original rubber bush from rear diff rear mounting position in the subframe.
2. Push the new A part polyurethane bush into the bore of the subframe from the rear of the car.  
Push the new B part polyurethane bush into the bore of the subframe from the front of the car.
3. Apply the supplied PTFE / Silicone grease to the bore and mounting faces of the bush and insert the sleeve into the A bush from the rear of the car.
4. Re-fit the diff to the car and tension all hardware to manufacturers recommended torque settings.

