

POWERFLEX®

PART NUMBER
PFR69-506

DESCRIPTION
REAR TRAILING ARM FRONT BUSH

INSTALLATION GUIDE

Contents (parts per car):

- 2 x bushes (4 polyurethane parts)
- 2 x metal sleeves
- 2 x metal washers 14mm hole
- 2 x metal washers 20.5mm hole
- 1 x grease

Please read the complete fitting instructions and check package components before fitment.

This installation guide is to be used in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licenced technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Installation Guide:

- Remove rear trailing arm, press out original bush
- Insert the 2 polyurethane top hat bushes into the arm, apply some of the supplied grease to the bore of the bush and outside of the stainless sleeve, slide the sleeve into the bush.
- Place the washer with the 20.5mm hole over the tube on the subframe, apply some grease to the faces of the bush and refit the arm.
- Place the washer with the 14mm hole onto the original bolt and tighten.

