

POWERFLEX®

PART NUMBER

PFR5-4617

DESCRIPTION

REAR UPPER ARM INNER BUSH

INSTALLATION GUIDE

Product description:

This part replaces OEM part number 33321092247.

Contents (parts per pack):

Bushes (2 x A, 2 x B)
2 x Stainless Steel Sleeves
1 x Grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bush from the arm. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
2. Push in the bushes into the arm. Be sure that the B bush (large bush) is facing the rear of the car.
3. Apply some of the supplied grease to the bore and end faces of the bush, push the stainless steel inner sleeve into the bush.
4. Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

