

POWERFLEX®

PART NUMBER
PFF57-801

DESCRIPTION
FRONT CONTROL ARM INNER BUSH

INSTALLATION GUIDE

Product description:

PFF57-801 ALLOWS ON CAR ADJUSTMENT OF THE CAMBER ANGLE.

Contents (parts per pack):

4 x bushes (2 x A part & 2 x B part)
2 x stainless steel adjustable sleeves
1 x C spanner
1 x grease

*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:*

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the front control arm, remove the inner bush front the arm, clean the arm of any dirt and corrosion.
2. Fit 1 A & 1 B part bush into the arm, lubricate the bore of the bushes with some of the supplied grease.
3. Fit the sleeve into the bush, the end with the adjustment wheel fits against the A bush with the thinner top section.
4. Refit the arm to the car, carry out alignment check. If the camber requires adjustment slacken the bolt, adjust the camber to the desired setting with the C spanner, re tighten the bolt and recheck alignment.

