

POWERFLEX®

PART NUMBER
PFR5-425

DESCRIPTION
REAR DIFF FRONT BUSH

INSTALLATION GUIDE

Product description:

This bush offers reduced movement on the rear diff which results in a reduction of the initial torque lost during acceleration

Contents (parts per pack):

- 4 x bushes
- 2 x stainless steel sleeves
- 2 x metal washers
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bushes from the subframe.
2. Fit the polyurethane parts into the subframe.
3. Using the supplied grease apply to the bore of the bush and the outside of the stainless steel sleeve. Push the sleeve through the bush.
4. Place a washer on the larger diameter of the front bush, use the original bolt and refit as necessary.

