

# POWERFLEX®

## PART NUMBER

**PFF5-5701**

## DESCRIPTION

**FRONT CONTROL ARM TO CHASSIS BUSH**

## INSTALLATION GUIDE

### Product description:

This part replaces OE number: 31126768818 and has been engineered to allow the control arm to be set in the original caster setting, or provide an increase in caster using an offset sleeve.

### Contents (parts per pack):

- 4 x Polyurethane bushes
- 2 x Stainless steel sleeves
- 1 x PTFE / Silicone Bush Assembly Grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*



### Fitting Instructions:

1. Remove the original rubber bushes from the control arm.
2. Clean any dirt and corrosion from the bore of the arm and remove any sharp edges using a file.
3. Fit the polyurethane bushes into the bore of the arm, apply some of the supplied PTFE / Silicone grease to the bore of each bush.
4. Fit the stainless steel sleeve to the bush, making note of the correct orientation shown below.
5. Tighten all hardware to manufacturers recommended torque settings.



Sleeve setting for original caster offset



Sleeve setting for maximum caster offset