

POWERFLEX®

PART NUMBER
PFF85-505

DESCRIPTION
LOWER ENGINE MOUNT SMALL BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x bush
- 1 x metal sleeve
- 1 x metal washer
- 1 x grease
- 1 x instructions



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the mount from the car.
2. Using a 15mm drill, drill the original bracket and sleeve allowing the bracket to come away from the sleeve in the bush. Make a note of which side the bracket fits onto the mount as the bracket will be reused.
3. Make sure the hole in the bracket measures 15mm.
4. Remove the original bush from the mount.
5. Fit the Powerflex bush into the mount, a little washing up liquid helps in the fitting.
6. Apply some of the supplied grease into the bore of the bush then fit the stainless steel sleeve, making sure the end with the small spigot faces towards the bracket side.
7. Fit the mount back onto the car. Place the washer between the bush and gearbox to create a smooth face. Make sure to refit the bracket you drilled off earlier over the spigot of the stainless steel sleeve.

