



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

**Wheel Clearance Template**  
 BMW E36 M3 and E46 M3  
 Radi-CAL Competition Packages,  
 355 mm disc, CP9660 Caliper

**essex parts services, inc.**  
 www.essexparts.com

Essex package no: 13.01.10085 (E36)  
 13.01.10065 (E46)

DWG. NO. **1677** REV