



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [.10 in.] clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template

Porsche 987 Cayman, 981, 718,
other modes, Front
CP9669 caliper, 355.6 mm disc

Essex package no. 13.01.10170
13.01.10171

essex parts
services, inc.
www.essexparts.com

DWG. NO. 2191 | REV

5

4

3

2

1