

POWERFLEX®

PART NUMBER
PFR69-516

DESCRIPTION
REAR DIFF REAR MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per car):

- 4 x bushes
- 2 x stainless steel sleeves
- 2 x special nuts
- 2 x steel washers 60mm OD, 12mm hole
- 2 x steel washers 67mm OD, 22.3mm hole
- 1 x grease



Please read the complete fitting instructions and check package components before fitment.

This installation guide is to be used in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licenced technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Installation Guide:

- Remove rear diff and remove original bushes from the subframe.
- Fit smaller 60mm washers onto studs, fit inner half of bush into sub frame.
- Refit diff, apply grease to stainless sleeve, insert stainless sleeve from the rear of sub frame and push in till it touches washer.
- Fit second half of bush from the rear of subframe, put larger washer onto the special nut, apply grease to nut and washer face and insert into bush, tighten.



Small Washer

