

POWERFLEX®

PART NUMBER
PFF19-1202

DESCRIPTION
FRONT LOWER WISHBONE REAR BUSH

Product description:

PFF19-1202 - FRONT LOWER WISHBONE REAR BUSH

Contents (parts per pack):

2 x bushes
1 x grease



*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:*

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove front lower wishbone from the car.
2. The original front wishbone rear bush is oil filled and caution must be taken when removing the original bush. Please also note Ford uses the same bracket for both sides they just insert the wishbone from the opposite end.
3. The safest and easiest way we found to remove the original bush was to first support the bracket and press the center metal part through, THIS SPLITS THE RUBBER ALLOWING THE OIL TO ESCAPE. Next using a blow torch or oxyacetylene burn the rubber away. Press out the alloy cage which is left in the bracket. Clean all the old rubber from the bracket. Cut the outer sleeve off the rear pin of the wishbone.
4. Lubricate the chamfered lip of the bush with soap, press the bush into the `open` end of the bracket until the tapered end pops out of the swaged lip.
5. Apply the supplied grease to the pin of the wishbone and push into the powerflex bush making sure the bracket is the correct way around. The pin fits into the end with the tapered recess.
6. Refit the wishbone to the car.