



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template

BMW E36 M3 and E46 M3
Radi-CAL Competition Packages,
355 mm disc, CP9668 Caliper

Essex package no: 13.01.10086 (E36)
13.01.10066 (E46)

**essex parts
services, inc.**
www.essexparts.com

DWG. NO. **1678** | REV