

Instructions:

- Print out and confirm the scale in both directions.
- 2. Cut out along the outer dotted lines.
- 3.
- Optional: Attach to a more rigid surface such as cardboard.
 Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.

 A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel
- 5. and suspension component flex.

Wheel Clearance Template
Porsche 987/981/718 Boxter S/ Cayman
S Rear Radi-CAL Competition Package,
340 mm disc, CP9451 Caliper

essex parts services, inc. www.essexparts.com

Essex package number: 13.01.10055

DWG. NO. 1650 REV

3