

POWERFLEX

PART NUMBER	DESCRIPTION
PFR30-334	REAR DIFF MOUNTING BUSH

INSTALLATION GUIDE

Product description:

This part replaces OEM part number 82410101

Contents (parts per pack):

4 x Polyurethane Bushes	2 x Stainless Steel Sleeves
4 x Steel Washers	1 x Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Press or burn the original bush out from the bracket
2. Clean any dirt and corrosion from the bore in the bracket. Remove any sharp edges from the bore of the bracket.
3. Push polyurethane bushes into bore of the bracket. Use supplied grease to ease insertion.
4. Apply some of the supplied grease to the bore and end faces of the bush, push the stainless steel sleeve into bush bore.
5. Place steel washers on the face of each bush.
6. Re-fit arm to the car. Tension all hardware to manufacturer's recommended torque settings.

