

POWERFLEX®

PART NUMBER
PFF5-402

DESCRIPTION
FRONT CONTROL ARM TO CHASSIS BUSH

INSTALLATION GUIDE

Product description:

PFF5-402 comes as an assembled bush ready to press into the front control arm, the bush is made up of a polyurethane ball bonded to the stainless steel sleeve which allows the bush to twist on the 2 stainless steel cups.

Contents (parts per pack):

2 x bush assemblies



*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:*

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the front lower control arm.
2. Make a note of which way around the offset sleeve is fitted then remove the bush from the arm.
3. The new bush needs to be pressed into the arm, make sure the longer sleeve on the new bush is fitted the same side as the original one.
4. Place the narrower end (shorter sleeve side) into the arm and press the bush in until it stops against the larger diameter on the outer shell.
5. Refit the arm back onto the car
6. Road test car.

