

POWERFLEX®

PART NUMBER

EXH030

DESCRIPTION

VAUXHALL REAR EXHAUST MOUNT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Exhaust Mount

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bush from the exhaust mounting bracket using a hacksaw or sharp knife, clean any dirt and corrosion from the bore in the bracket.
2. Push the new polyurethane exhaust mount into the bracket, making note of its correct orientation. We recommend using a G clamp or a vice to push in the exhaust mount.

Fitting tips: Smear washing up liquid on the outside of the bush, make sure there is enough space under the bracket to allow the bush to come through the other side. Support the bracket when pushing the bush in. The Black Series is a stiffer material and will be more difficult to fit. More care needs to be taken, so not to damage the bracket, when fitting the bush into the bracket.

Although you can remove the bracket from the car to make the procedure easier, it should be possible to fit the bush with the bracket remaining on the vehicle.

