

# POWERFLEX®

PART NUMBER

**EXH035**

DESCRIPTION

**BMW EXHAUST MOUNTING BUSH & BRACKET**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 1 x Polyurethane Bush
- 1 x Anodised Aluminium Bracket
- 2 x M8 Flanged Nuts

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

### Fitting Instructions:

1. Remove the original exhaust mount from the car.
2. Fit the Powerflex exhaust mount to the car, with the M8 flanged nuts, in the same position as the old one. Make sure the offset bore sits towards the ground once fitted.
3. Fit the exhaust mount support bolt through the bore of the polyurethane bush, and tension all hardware to manufacturers recommended torque settings.

