



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [0.10 in.] clearance is recommended to account for wheel and suspension component flex.

Wheel Clearance Template
 Radi-CAL Competition Package
 BMW G80 M3 / G87 M2, Rear
 CP9449 Caliper, 365 mm Disc, no EPB

**essex parts
 services, inc.**
 www.essexparts.com

Essex package no. 13.01.10176

DWG. NO. **2227** REV