

# POWERFLEX

**PART NUMBER**  
**PFF3-802G**

**DESCRIPTION**  
FRONT LOWER RADIUS ARM TO CHASSIS BUSH -  
CASTER ADJUSTED

## INSTALLATION GUIDE

### Contents (parts per pack):

4 x Polyurethane bushes	2 x Steel washers
2 x Stainless steel sleeves	2 x Steel outer shells
1 x Spanner	1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.



### Fitting Instructions:

1. Remove the original bush from the arm.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
3. Press steel outer shell into bore of arm, pressing on the machined face with the smaller diameter lip side leading. Press till the larger diameter lip sits flush on machined face of arm.
4. Fit each polyurethane bush into bore of the shell.
5. Apply some provided grease to bore and mounting faces of each bush. Fit the stainless steel sleeve into bush with machined sleeve face facing towards the centre of vehicle *figure 1*.
6. Place washers flush against top face of exposed polyurethane bush faces.
- 7 Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

