



PART NUMBER  
**PFF19-199**

DESCRIPTION  
**FRONT TOP SHOCK ABSORBER MOUNT**

### INSTALLATION GUIDE

#### Contents (parts per pack):

- 2 x Polyurethane A Bushes
- 2 x Polyurethane B Bushes

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

#### Fitting Instructions:

1. Gain access to the front shock absorber strut. Retain the original metal cap for refitting.
2. Push the polyurethane part A onto the strut with the larger face first, so it sits on the upper spring cup, as shown in figure 1.
3. Polyurethane part A sits underneath the inner wing, so ensure there is contact between the polyurethane part and the inner wing.
4. Fit the polyurethane part B onto the strut with the flat surface facing upwards, so it sits on top of the inner wing, as shown in figure 2.
5. Refit the metal cap and fasten the bolt, tensioning all hardware to manufacturers recommended torque settings.



Figure 1



Figure 2



Figure 3