

POWERFLEX®

PART NUMBER

PFF1-410

DESCRIPTION

GEARBOX MOUNT REAR INSERT KIT

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane A Bushes

2 x Polyurethane B Bushes

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bolts from the gearbox mount and retain them for refitting.
2. Clean any dirt and corrosion from the mount, and file of any sharp edges.
3. Insert the polyurethane A part into the voids of the mount until it sits in contact with the surface of the mount. Repeat this for the opposite side of the mount.
4. When refitting the original bolts, place the polyurethane B parts, which act like washers, on the outside surface of the A parts, as shown in figure 1.
5. Tension all hardware to manufacturers recommended torque settings.

