

POWERFLEX®

PART NUMBER
PFF85-802

DESCRIPTION
FRONT WISHBONE REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane Bushes 1 x PTFE/Silicone Grease
- 2 x Stainless Steel Sleeves
- 2 x Zinc Plated Mild Steel Outer Shells

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bush from the front wishbone.
2. Clean any dirt and corrosion from the bore of the arm, and file off any sharp edges.
3. Push the outer shell into the bore, smaller diameter first, from the top of the arm.
4. Push the polyurethane part into the bore of the outer shell, smaller diameter first. **TIP: Apply some washing up liquid around the polyurethane part to aid in fitting.**
5. Apply some of the supplied grease to the bore of the polyurethane part and push the stainless steel sleeve into the bore so it sits flush inside the bush. For maximum caster adjustment, the offset holes in the sleeves must be closest to the middle of the car, as shown in figure 1.
6. Tension all hardware to manufacturers recommended torque settings.




Figure 1




Figure 2

POWERFLEX®

PART NUMBER

PFR85-816

DESCRIPTION

REAR TRAILING ARM FRONT BUSH

INSTALLATION GUIDE

Product description:

This part replaces OEM part number 5Q0505541A.

Contents (parts per pack):

2 x 'A' Polyurethane Bushes 4 x 'B' Polyurethane Bushes 2 x Stainless steel sleeves 1 x Grease


*Please read the complete fitting instructions and check package components before fitment.
 These fitting instructions are to be used as a guide and in conjunction with workshop manual.
 It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the rear trailing arm from the car.
2. Push out the rubber bush from the arm. Fig A.
3. Remove any sharp edges and clean any dirt or corrosion from the arm bore.
4. Fit the new large 'A' PU bush into the arm, with the smaller diameter facing towards the outer face of the arm. Fig B.
5. Insert the two smaller 'B' PU bushes from both sides into the 'A' PU. Fig B.
6. Apply some of the supplied grease in the bore of the bush and insert the stainless steel sleeves into the bore. Fig B.
7. Fit back trailing arm to the car. Tension all hardware to manufacturers recommended torque settings.



POWERFLEX®

PART NUMBER

PFF85-832

DESCRIPTION

LOWER ENGINE MOUNT INSERT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Bush 1 x PTFE Silicone Grease
1 x Metal Outer Shell 1 x Metal Washer

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Use PFF85-832 Or PFF85-833 For OEM part number 500198 037 B



Fitting Instructions:

1. Access the lower engine mount which is located in the front sub frame under the car.
2. Remove the bolt from the lower engine mount.

Note: the manufacturer's bolts are stretch bolts and new bolts are recommended on re-fit.

3. The insert pushes into the voids of the original bush. Remove any flash lines and clean the dirt from the voidings.
4. Slide the new PU insert into the voids of the rubber bush, as shown in Figure 1.
5. Position the supplied washer on top of the PU insert. Push the supplied sleeve into the bore of the washer, as shown in Figure 1.
6. Use the original bolt and small washer to secure the PU insert kit into the rubber engine mount, as shown in Figure 1.
7. Tension all hardware to manufacturers recommended torque settings.




Figure 1 - assembly of PFF85-832 in the engine mount